



4	05-24-30 var. 05-24-507	
5	01-45617 tillkommit	83-0-03 U
6	01-53163-2 var. 01-42122-2	80
7	808522 var. 804471	
8	10-24130-2 var. 10-24130-1	83-023 U
9	01-45634 var. 01-46318	
284	P10 10-24130-3 och 10-24130-4 tillkom	870/3 RE
283	P11 Träning av lösnöckling	85.06.26 U

Endcover	10-24130-4	F8B-905	01-42422-1	01-35163-2
Lock	10-24130-3	F8B-905	01-45317	01-46129-1
Cam Nr.				
Pump No.				
Pump Typ				
Kam Nr.				
Lock				

Part No.	Part Name	Description	Material	Dimensions
15	Washer	15	Bricka	01-45617
17	Screw	17	Skrv	06-04-178
16	Screw	16	Skrv	05-04-108
14	Lip seal	14	Lipstämning	05-25-510
13	Ball bearing	13	Kullager	6306 2RS
12	Spacer	12	Distansstycke	05-01-609
11	Retaining ring	11	Lagering	05-34-118
10	Gasket	10	Axel	01-45354
9	Washer	9	Bricka	01-45634
8	Washer	8	Bricka	01-42422-1/3
7	Washer	7	Bricka	01-42422-1/3
6	Washer	6	Bricka	01-42422-1/3
4	Impeller	4	Impeller	08-023 B
3	Cam	3	Kam	5.8.14.14
2	Lock	2	Lösnöckling	5.3.1300 U
1	Body	1	Pumpkropp	01-13007

87	05-04-178 var. 05-04-178	712 886 U
88	01-45634 var. 01-46318	4.6.1300 U
89	01-45634 var. 01-46318	5.3.1300 U